



## **PLATFORM CABINET TROUBLE SHOOTING**

### **Cabinet will not rewind**

- Check all electrical power breakers, reset if tripped.
- Push both (2) test lights, insure they light up when pressed, if not check breakers and power supply to cabinet.
- Check auto interrupt switch, (located inside cabinet, on front side of hose reel) insure spring pushes arm out. It must be in the out position to work, when pulled in towards the hose reel, against interrupt switch, it will break power and won't allow reel to wind in.
- Check chain, replace and or adjust if it has come off.
- If after all tests are performed and reel will not rewind, call factory for technical advice.

### **Cabinet leaks**

- Check to insure all fittings are tight.
- If hose leaks, replace.
- If swivel on reel leaks, repair or replace.
- If either reel leaks, it is possible to isolate leaking reel and still use opposite reel by turning off water supply valve located nearest to that reel to that reel only. If elected, turn off water supply to both reels by shutting off main supply valve, located in center of cabinet.
- If backflow preventer leaks, see instructions located in this booklet.

**For Any Additional Questions or Comments, Please Call  
Snyder Equipment Co. Inc.  
1-800-641-4512**

